

Display Saver Mode (Firmware Version 3.50 or higher)

The front panel display is a Vacuum Fluorescent Display (VFD).

The VFD automatically enters the "Display Saver Mode" if no front panel key is operated for 20 minutes.

In this mode, "DISPLAY SAVER MODE. PRESS ANY KEY" message scrolls sideways on the VFD.

The VFD reverts to normal mode if any key is pressed.

This one-touch key operation serves only to restore the VFD to the normal operating state.

Subsequent key operation is effective for operation of the amplifier.

*The VFD is a consumable item. The VFD brightness decreases by half after about 30000 hours of continuous lighting.

The Firmware Version 3.50 "Display Saver Mode" automatically dims the VFD light during the message and will extend the life of the VFD.