

BACK CAN

HY-BC1

Please follow the instructions in this manual to obtain the optimum results from this unit.
We also recommend that you keep this manual handy for future reference.

1. SAFETY PRECAUTIONS

- Be sure to read the instructions in this section carefully before use.
- Make sure to observe the instructions in this manual as the conventions of safety symbols and messages regarded as very important precautions are included.
- We also recommend you keep this instruction manual handy for future reference.

Safety Symbol and Message Conventions

Safety symbols and messages described below are used in this manual to prevent bodily injury and property damage which could result from mishandling. Before operating your product, read this manual first and understand the safety symbols and messages so you are thoroughly aware of the potential safety hazards.



WARNING

Indicates a potentially hazardous situation which, if mishandled, could result in death or serious personal injury.

- Leave the installation to your TOA dealer because the installation requires expert knowledge. Improper installation may cause the speaker to fall, resulting in personal injury and/or property damage.
- Install the mounting hardware in a location that can structurally support the weight of the mounting hardware and the speaker. Doing otherwise may result in the speaker falling down and causing personal injury and/or property damage.
- Do not use other methods than specified to mount the unit. Extreme force is applied to the unit and the unit could fall off, possibly resulting in personal injuries.
- Use nuts and bolts that are appropriate for the ceiling's or wall's structure and composition. Failure to do so may cause the speaker to fall, resulting in material damage and possible personal injury.
- Tighten each nut and bolt securely. Ensure that the unit has no loose joints after installation to prevent accidents that could result in personal injury.
- Use the specified speaker in combination. Doing otherwise may cause the speaker or component to fall off, resulting in personal injury.



CAUTION

Indicates a potentially hazardous situation which, if mishandled, could result in moderate or minor personal injury, and/or property damage.


- Do not stand or sit on, nor hang down from the mounting hardware as this may cause it to fall off, resulting in personal injury and/or property damage.
- Avoid touching the unit's sharp metal edge to prevent injury.

2. GENERAL DESCRIPTION

The HY-BC1 Back Can is a metal case to be used when installing the flush-mounted ceiling speaker in exposed applications. Mount the Back Can to a ceiling suspension pipe.

3. INSTALLATION

Refer to the speaker's instruction manual for information.



4. SPECIFICATIONS

Finish	Surface-treated steel plate, black, paint
Weight	1.5 kg
Usable Speaker	F-122C, F-122CU, F-2322C, F-2352C, F-2352SC

Note: The design and specifications are subject to change without notice for improvement.

• **Accessories**

Rubber grommet 2